


ASW300 SERIES SLIDING WINDOW SUBJECT: INSTALLATION DETAILS - 1

TECHNICAL MANUAL

PAGE: ASW300.3.10.1

DATE: MAY 2013

# HEAD DETAIL (CAVITY BRICKWORK)






ASW300 SERIES SLIDING WINDOW SUBJECT: INSTALLATION DETAILS - 2

TECHNICAL MANUAL

PAGE: ASW300.3.10.2

DATE: MAY 2013

# SILL DETAIL (CAVITY BRICKWORK)



Provide additional support for all DG windows and all windows over 1800 wide (by builder)




ASW300 SERIES SLIDING WINDOW SUBJECT: INSTALLATION DETAILS - 3

TECHNICAL MANUAL

PAGE: ASW300.3.10.3

**DATE: MAY 2013** 

## JAMB DETAIL (CAVITY BRICKWORK)






ASW300 SERIES SLIDING WINDOW SUBJECT: INSTALLATION DETAILS - 4

TECHNICAL MANUAL

PAGE: ASW300.3.10.4

DATE: MAY 2013

# **HEAD DETAIL** (WEATHERBOARDS)






ASW300 SERIES SLIDING WINDOW SUBJECT: INSTALLATION DETAILS - 5

TECHNICAL MANUAL

PAGE: ASW300.3.10.5

DATE: MAY 2013

# SILL DETAIL (WEATHERBOARDS)





ASW300 SERIES SLIDING WINDOW SUBJECT: INSTALLATION DETAILS - 6

TECHNICAL MANUAL

PAGE: ASW300.3.10.6

**DATE: MAY 2013** 

## JAMB DETAIL (WEATHERBOARDS)

